

PRO-WESTERN PLASTICS

747 - 647 UN PAIL

LID APPLICATION



USE A MINIMUM 3 LB DEAD BLOW HAMMER.
DO NOT USE A RUBBER MALLET.



**STRIKE THE LID
WITH THE MALLET
ANGLED SLIGHTLY
ALONG THE
OUTER EDGE
OF THE LID.**



**DO NOT
STRIKE THE LID
FLAT ALONG
THE TOP OF
THE LID!**



**DO NOT
STRIKE THE LID
ALONG THE
INSIDE EDGE
OF THE LID!**

**LID APPLICATION VIDEO AVAILABLE ONLINE AT
www.pro-westernplastics.com**



START THE LID IN ONE LOCATION. MOVE AROUND THE LID IN A COUNTER CLOCK WISE DIRECTION, STRIKING THE PERIMETER OF THE LID 6-8 TIMES.



**PLEASE CONTACT YOUR
PRO-WESTERN PLASTICS
TERRITORY MANAGER
FOR ADDITIONAL INFORMATION.**

PRO-WESTERN
PLASTICS LTD 

LID APPLICATION VIDEO AVAILABLE ONLINE AT
www.pro-westernplastics.com